MACCS 200 LEVEL Training & Readiness (T & R) Instruction

Data Link Symbology A-16

Supplemental Handout

THERE ARE THREE BASIC SYMBOL SHAPES:

	CLASSIFICATION	COLOR
CIRCLE	(FRIENDS)	(GREEN)
DIAMOND	(HOSTILES)	(YELLOW)
SQUARE	(UNKNOWNS)	(YELLOW)

TITLE	SYMBOL	ID CATEGORIES	COMMENTS
PENDING	YELLOW	UNKNOWN Pending General	
EVALUATED UNKNOWN	YELLOW	UNKNOWN Evaluated General Bomber Fighter AEW/RECCE/ EW/DECOY Helo/Trans Missile Platform Zombie	
ASSUMED ENEMY	YELLOW	UNKNOWN Assumed Enemy General Bomber Fighter AEW/RECCE/ EW/Decoy Helo/Trans Missile Platform X-Ray	

TITLE	SYMBOL	ID CATEGORIES	COMMENTS
ASSUMED FRIEND	YELLOW	UNKNOWN Assumed Friend General Bomber Fighter AEW/RECCE/ EW/DECOY Helo/Trans Missile Platform	
INTERCEPTOR	GREEN	FRIEND Interceptor Fighter General Unavailable RESCAP (with SAR Modifier) CAP RTB (with modifier)	
F-14	GREEN	FRIEND Interceptor/ Fighter F-14 (AEW)	F-14 symbol will be displayed for F-14 aircraft, or locally controlled aircraft with esatblished two-way TADIL-C datalink communications

TITLE	SYMBOL	ID CATEGORIES	COMMENTS
MISCELLANEOUS FRIEND	GREEN	FRIEND General General Neutral Nonmilitary Missile Training RTB (with modifier) Special mission General AEW/ARP/ABCCC EW (with modifier) Recon Kilo/Yoke Strike Support ASW Logistics General	
FAKER	GREEN	FRIEND General Neutralized Faker Special Mission Faker	
NATO FAKER	GREEN	FRIEND Special Mission Jammer (Faker NATO)	

TITLE	SYMBOL	ID CATEGORIES	COMMENTS
HELICOPTER	GREEN	FRIEND Helicopter General ASW Gunship Recon/RECCE Logistic Troop-Lift Medevac SAR (with modifier)	
CAS/DAS	GREEN	FRIEND Strike Support CAS/DAS Interdiction	
TANKER	GREEN	FRIEND Strike Support Tanker General Tanker (Boom) Tanker (Drogue)	
HOSTILE	YELLOW	HOSTILE General Genera Bomber Fighter Helo/Trans Missile Platform Jammer (with modifier) AEW/RECCE/EW/ Decoy (with modifier)I	

TITLE	SYMBOL	ID CATEGORIES	COMMENTS
MISSILE	YELLOW	HOSTILE General Missile	
TACAN	GREEN	FRIEND Station Air TACAN (Point)	
ECM FIX (POINT)	YELLOW	HOSTILE ECM Fix General (Point)	
HAZARD (POINT)	ORANGE	HOSTILE Hazard (Point) General NAV Mine Impact Point Ground Zero AIM/WPN entry point ECM Decoy	
AIRBASE	GREEN	FRIEND Supporting Unit Airbase	

TITLE	SYMBOL	ID CATEGORIES	COMMENTS
REFERENCE POINT	GREEN	FRIEND Reference Point General Marshall Point Waypoint Corridor TAB PIM Dspn Center Form Center Search Area Point Station General General Tomcat Picket Rendezvous Replenishment Rescue Station Air General CAP AEW ASW Fixed Wing ASW Helo Replenishment Strike IP	
FIRE UNIT	GREEN	FRIEND Supporting Unit SAM Site	

TITLE	SYMBOL	ID CATEGORIES	COMMENTS
OTHER CENTER	GREEN	FRIEND Site General FPU/FRU PU RU Supporting Unit General MHQ ASRT DASC FACP ADA/BOC/TDS	Own TAOC. Displayed at selected symbol brightness
EMERGENCY FIX	GREEN	FRIEND Emergency General Downed aircraft Man in water Distressed vessel	Displayed at selected symbol brightness
RADAR	GREEN	FRIENDLY RADAR SITES OWN TAOC RADAR and remote RADARs, including other site RADARs	
HOSTILE POINT	YELLOW	HOSTILE Strike Hostile General Troops Airbase Artillery Convoy Rail Bridge	

TITLE	SYMBOL	ID CATEGORIES	COMMENTS
SHIP-UNKNOWN	YELLOW	SHIP Unknown Pending General Evaluated General CV CA/DD FPB Amphibious Nonmilitary Surfaced Sub SIGINT Assumed Friend General CV CA/DD FPB Amphibious Nonmilitary Surfaced Sub SIGINT Assumed Friend General CV CA/DD FPB Amphibious Nonmilitary Surfaced Sub SIGINT Assumed Enemy General CV CA/DD FPB Amphibious Nonmilitary Surfaced Sub SIGINT	

TITLE	SYMBOL	ID CATEGORIES	COMMENTS
SHIP-FRIEND	GREEN	SHIP Friend General Neutral Nonmilitary Auxiliary General Tanker Cargo Troop Repair Hospital Special General FPB Minelayer O RSH SIGINT ACV/H Surfaced Sub Mines Line General CV CA DL DD DE Patrol Amphibious General L-Platform L-Ship L-Craft Troop Cargo Command LHA	

TITLE	SYMBOL	ID CATEGORIES	COMMENTS
SHIP-HOSTILE	YELLOW	SHIP Hostile General CV CA/DD FPB Amphibious Nonmilitary Surfaced Sub SIGINT	
POINTER (RECEIVE)	ORANGE ← W	SHIP Hostile General CV CA/DD FPB Amphibious Nonmilitary Surfaced Sub	Pointer will appear on receiving console, and all other consoles with same position selected Letter W, T, E, or S indicates position type Symbol will blink when used as internal comm mark
POINTER (TRANSMIT)	ORANGE ← W	POINTER Data link Internal comm	Pointer will appear on sending console, and all other consoles with same position selected Letter W, T, E, or S indicates position type Symbol will blink when used as internal comm mark
LOW ALTITUDE AIR DEFENSE TEAM (LAAD)	GREEN		Displayed when SYM DSPL FFS, OTHER CENTER VFS is selected

TITLE	SYMBOL	ID CATEGORIES	COMMENTS
FINGER POST	YELLOW		
HOOK MARKER	GREEN		
SITE (OUT OF DISPLAYABLE RANGE)	GREEN	FRIEND Site General FPU/FRU PU RU	When OTHER CENTER VFS in SYM DSPL FFS array is selected, all sites and supporting units are displayed. any units outside of 1024 by 1024 dm system grid, but within the 2048 by 2048 dm system grid, will be displayed at one-half their range from system center.
FRIENDLY RAID GATE	GREEN		30 max raid gates, friendly and hostile
HOSTILE RAID GATE	YELLOW		30 max raid gates, friendly and hostile

MODIFIER	EXAMPLE	COMMENTS
SIZE EXPANSION SYMBOL EXPANDS TO TWO TIMES NORMAL SIZE		Occurs when track is designated as lost When basic symbol expands, modifier RTB, SAR, jammer, engaged, other report, TADIL-C, down-link, incoming order will expand. Pairing lines and ASCII will not expand.
BLINK CONDITION BLINKS AT 0.5 SECOND RATE. AFTER 20 SECONDS, BLINKS AT 2 SECOND RATE		Symbols are blinked as alert for lost track, emergency, category conflict, and unassigned hostile. Pairing lines are blinked for impossible intercept, unacknowledged FU assignment. Pointer symbol is blinked for internal comm mark. When symbol blinks, modifiers of RTB, SAR, jammer, do not intercept, and engaged will blink. Solid pairing lines, dashed pairing lines, other report, ATDL report, TADIL-C up-link, TADIL-C down-link, incoming order, outgoing order, and ASCII character blink is separately controlled
PAIRING LINE	A	Display for symbols that are paired, join-up, waypoint, engaged, incoming orders, outgoing orders Color and intensity are same as for friendly symbol
DASHED PAIRING LINE		Indicates trial pairing or trial intercept. Also used between track and base on RTB incoming or outgoing order and between track and unit to receive control on transfer control incoming or outgoing order

TITLE	SYMBOL	COMMENTS
DASH-DOT-DOT PAIRING LINE		Indicates data source for paired symbols is EW or intelligence. Pairing line is removed when either symbol is dropped, or a category is changed to "surface" or "spare"
OTHER REPORT		Displayed with air and surface tracks when data source is via TADIL-A, TADIL-B, or LINK-1 from units with reporting responsibility
ATDL REPORT		Displayed when data used is received from missile battery via ATDL
TADIL-C DOWN-LINK		Displayed when data used is received from TADIL-C aircraft via TADIL-C
TADIL-C UP-LINK		Displayed when track is transmitted to TADIL-C aircraft via TADIL-C. If TADIL-C up-link and down-link conditions coexist, down-link modifier has precedence for display

TITLE	SYMBOL	COMMENTS
INCOMING ORDER		Displayed with any data link message requiring operator action. Orders that cause display are: engage, investigate/assign, cover, cease engage, cease fire, hold fire, salvo, RTB, transfer control, handover, and change data. Status messages that cause display are no track, engaging target, TUMA, weapons tight, weapons free, and RTB Modifier blinks at 2-Hz rate; modifier will temporarily supersede other report, TADIL-C up-link, TADIL-C down-link, outgoing order, and ATDL report Status cleared by CANTCO or WILCO
OUTGOING ORDER		Displayed upon operator initiation of data link transmission. Commands that cause display are: engage, investigate/assign, cover, cease engage, cease fire, hold fire, salvo, RTB, transfer control, handover, initiate track, priority kill, destroy, challenge, disengage, drop track, weapons free, weapons tight, change data, and clear IFF Order modifier will blink under following conditions: receipt of CANTCO, receipt of CANTPRO, no machine receipt to order, no receipt compliance within 2 minutes of machine receipt, to addressed order
RETURN TO BASE (RTB)	X	Displayed only on friendly air tracks designated as RTB Mutually exclusive with SAR and jammer. Latest designated supersedes others
JAMMER		Displayed only with helo and faker when designated bu operator as having jammer capabilities Mutually exclusive with RTB and jammer. Latest designated supersedes others

TITLE	SYMBOL	COMMENTS
SEARCH AND RESCUE (SAR)	<u> </u>	Displayed only with heloand special mission Mutually exclusive with RTB and jammer. Latest designated supersedes others
ENGAGED		Displayed only with interceptor, F-14 interceptor, evaluated unknown, assumed friend, assumed enemy, hostile, faker, fire unit, ship, site. Not used in join-up or waypoint assignment Color same as basic symbol
DO NOT INTERCEPT (DNI) OR WEAPONS EXCLUSION	×	Displayed when DNI is designated on hooked track or when weapon is designated for exclusion for semi or automatic trials
ASCII CHARACTER - AIR TRACKS	C, E, H, K, R, S, T, M, I, D, 3, U, or N	Only one ASCII character is displayed at a time with the following priority 1. Emergency 2. PU Track 3. Heads up 4. Salvo 5. Conflict 6. Kill 7. Invalid NATO Mode 3 8. Special Mode 3 9. SPI Track 10. Data Recording 11. Rate Aided 12. Manual Auto 13. Tentative Symbols with following modifiers blink: 1. Emergency 2. Salvo 3. Conflict

TITLE	SYMBOL	COMMENTS
EMERGENCY	E	Denotes emergency on friendly track. Manually entered or by receipt of emergency IFF code.
CONFLICT	С	Denotes identity or category conflict
KILL OR GRAND SLAM	K	Denotes kill or effective engagement. Operator entered or received by data link
HEADS UP	Н	Received by data link. Denotes engagement not effective or FU engaged to other track than assigned. May be operator entered
SALVO	S	Denotes salvo condition either operator generated or received by data link
RATE-AIDED	R	Denotes operator initiation of rate-aided track
MANUAL AUTO	M	Denotes track was established manually as auto track, but is not being tracked automatically based on RADAR reports
TENTATIVE	T	Denotes tentative track established by operator
DATA RECORDING	D	Denotes that data recording initiated for track
SPI TRACK	I	Denotes special processing indicator track
SPECIAL MODE 3	3	Denotes track is responding with special nonemergency Mode 3 code
PU TRACK	U	Denotes track is identified as participating unit
INVALID NATO MODE 3	N	Denotes friend track has invalid Mode 3 code for current validity interval

TITLE	SYMBOL	COMMENTS
ASCII CHARACTERS FIRE UNITS	B, K, F, O, R, T, and A	
ENGAGEMENT BROKEN	В	Denotes assigned engagement has been broken by FU Normally received by data link, but may be be operator entered
ENGAGEMENT EFFECTIVE	K	Denotes engaged target is destroyed or neutralized
FIRING	F	Denotes FU is firing at assigned target
OUT OF ACTION	0	Denotes FU is out of action
READY	R	Denotes FU is available for assignment
TRACKING	Т	Denotes FU is tracking assigned target
WEAPONS ASSIGNED	Α	Denotes that requested assignment has been assigned to FU

ASCII CHARACTER - SURFACE TRACKS KILL OR GRAND SLAM	K	Denotes kill or effective engagement against surface track
ASCII CHARACTER - POINTS KILL OR GRAND SLAM	K	Denotes kill or effective engagement against point